


SMART IPCAMERA


Quick User Manual



CE FC ROHS


Packing Details

Please check the condition of camera after opening the color box, and the details of the accessories are shown below:



Product Details


Please check the interface and buttons of the camera before using.



Preparations: How to Configure Device

Note: Voice prompts are available throughout the configuration process. Memory card can be installed first, then connect the device to the power supply; (Memory card does not support plugging in and out of power, please plug in and out of the device after power off.)

Configure Device via WiFi




How to Download APP

Method1:
A. Open your mobile app (e.g. Facebook/Twitter/WeChat)
B. Scan the following QR code to see, then enter the mobile store to download
Method2:
Search "IC See" in the mobile APP store directly and download.





User registration & login


- If you have a We Chat or Facebook ID, you can use the "Quick Login" on the APP interface directly.
- You can also create a new username and login: Click "Sign Up" to get a new account & password.
- Enter a new username and password.
- Use the email account as the account to verify the account details via email to complete the registration.
- Then login using the username and password you just registered.




Method 1: Matching a device via WiFi (recommended)



Method 2 of matching device: Via Lan Port



Method 3 of matching device: Via AP Mode



FAQ:

Q: how to restore factory Settings?
A: Press and hold the RESET button on the back of the device for 5-10 seconds, and you can let go when you hear "restore factory settings".

Q: why can't I connect to the device?
A: please check the following conditions before connecting to the network:
1. If the wifi is 5G frequency band, please switch to 2.4G frequency band. 5G frequency band and dual frequency band are not okay.
2. When matching for the first time, keep the distance between the camera, router and mobile phone within 1-2 meters. (If the router pages, the signal range will decrease, so please be close to the router)
3. Whether the Wifi name is hidden, please make sure the router has no blacklist.
4. The router is not bound to a MAC address. (A stronger connection to the Internet by connecting your wifi, which means there is no bound MAC address.)
5. Try to avoid using a secondary router, and the instability of the wireless bridge router will cause the networking to fail.
6. Wifi uses a Wifi transmitter (such as 360Wifi, TP transmitter, etc.). If you connect this transmitter to your computer to transmit signals, it will be very unstable.

Q: how to store video?
A: 1. Use an external TF card, support up to 8-128GB memory card, automatically cycle after storage. Overwrite the oldest video content;
2. Charge cloud storage, free experience 30 days alarm picture video storage service, such as after 30 days. Continue to use the renewal fee, open the APP cloud storage center to view the charging standard.

Q: how to deal with the memory card is not recognized?
A: Power off the camera and restart or insert the card into the computer to read and format before installing it back to the camera.
Note:
1. The memory card cannot be assembled or disassembled while the device is powered on. If the memory card is not inserted when the camera is powered on, the device cannot recognize the memory card. Please insert the memory card after the device is powered off.
2. To ensure the quality of the memory card is good, it is recommended to use the "Kingston" "Sandisk" "Toshiba" original brand C10 read and write speed memory card, do not use fake upgrade memory card and neutral card.



Q: how to deal with it when the device is abnormally offline?
A: 1. Check if the equipment power, plug, cable and socket are okay;
2. Check if the network is normal;
3. Keep the distance between the router and the device within 10 meters;
4. Have you changed the router password or replaced the router;
5. If the above situation is ok, please restore the factory settings and reconfigure the device.

Q: how to switch networks?
A: 1. Open the Settings Center - Network Configuration - select the new WiFi and enter the password to configure;
2. Restore the factory, delete the devices list, and reconfigure in the new network;

Q: Why does the RESET button not respond when the device is turned on?
A: When pressing the RESET button, please keep the device powered on, and then press the RESET button for 5-8 seconds.

Note
● Please refer to the actual product, the manual is for reference only;
● APP and device firmware will be updated occasionally. If there is an upgrade later, please upgrade directly online, there will be no other notifications;
● The manual may be technically inaccurate or inconsistent with the function of the product or the wrong place of printing. Please refer to the final explanation of the company;

Special Declaration:
● Please take the real product as the standard. The manual is for reference only.
● APP and firmware of products and devices will be updated from time to time. If upgraded, please finish it in 10 hours, there won't be further reminder.
● The manual may contain technical inaccuracies, or inconsistencies with product functions or misprints, and the final interpretation right belongs to the company.



常见问题解析

Q: 如何恢复出厂设置?
A: 按住摄像头背部 "Reset" 键 5-10 秒, 当您听到 "恢复出厂设置" 即可放手。

Q: 为什么我连接不上设备?
A: 在摄像头连接到网络之前, 请检查以下问题:
1. 如果wifi是5G频段, 请切换到2.4G频段, 5G频段和双频段不能连接匹配;
2. 第一次匹配在1-2米内, 摄像头/路由器/手机。(如果路由器老化, 信号距离将减小, 所以请保证距离路由器更接近点);
3. WiFi名称未隐藏, 请确保路由器未设置黑名单;
4. 路由器没有绑定MAC地址。(陌生人连接你的wifi也可以访问互联网, 也就是说, 没有绑定的MAC地址。)
5. 尽量避免使用辅助路由器, 无线网桥路由器不稳定会导致连接不上;
6. WiFi使用了WiFi发射器(如360WiFi, TP发射器等)。这种发射器连接到计算机传输信号, 不稳定性相对较大。

Q: 设备如何存储录像?
A: 1. 使用外置TF卡, 最大支持8-128GB存储卡, 在存储满后将自动循环覆盖最早视频内容;
2. 收费云存储, 免费体验30天报警图片视频存储服务, 如30天后需继续使用需要续费, 收费标准请打开APP云存储中心查看即可;
Q: 内存卡无法识别怎么处理?
A: 断电重启摄像头或插入电脑读取将内存卡格式化再安装摄像头;
注意: 1. 内存卡不支持通电中插拔, 如果在摄像头通电情况下插入内存卡, 会造成无法识别内存卡, 请断电情况下插入内存卡
2. 确保内存卡本身无质量问题, 建议采用"金士顿" "闪迪" "东芝" 原装品牌C10读写速度内存卡, 不要使用假冒伪劣的升级内存卡和中性卡;

Q: 设备异常离线, 如何解决?
A: 1. 检查设备电源是否出现问题没有通电, 插头和线和插座逐一检查排除;
2. 检查家里的网络宽带是否正常;
3. 路由器和设备距离请保持在10米内为正常标准;
4. 是否更换了路由器密码或者更换路由器;
5. 以上正常的话, 请恢复出厂设置, 重新配对下设备;

Q: 如何切换网络环境?
A: 1. 打开设置中心-网络配置-选择新的WiFi名称输入密码配置;
2. 直接恢复出厂, 删除列表中心设备, 重新在新的网络配对一次即可;

Q: 为何开机后, 按RESET键没有反应?
A: 按RESET键时, 请保持设备通电状态中, 再长按RESET键5-8秒;

注意
● 请在使用的同时修改用户密码, 以免被不法分子盗用。
● 请勿将设备安装在潮湿、有灰尘、儿童容易接触到的场所。
● 请在允许的温度范围内使用和贮存, 切勿随意拆卸设备。

特别声明:
● 产品请以实物为准, 说明书仅供参考;
● APP和产品设备固件不定期更新, 如有升级请自行在线升级, 恕不另行通知;
● 说明书可能包含技术上不准确的地方, 或与产品功能不相符的或印刷错误;
● 的地方, 请以本公司最终解释为准;